

WELL PLUGGING PLAN
CTV I ELK HILLS 26R PROJECT

Injection Well 363C-27R

Facility Information

Facility Name: Elk Hills 26R Storage Project

Facility Contact: Travis Hurst / CCS Project Manager
28590 Highway 119
Tupman, CA 93276
(661) 342-2409 / Travis.Hurst@crc.com

Well Location: Elk Hills Oil Field, Kern County, CA
35.32802963 / -119.5449982

Version History

File Name	Version	Date	Description of Change
Attachment G – COP Details_363C-27R	1	05/31/22	Original document, combines well construction, operating procedures, and plugging plan into injection well narrative document.
Attachment G – COP Details_363C-27R_V2	2	12/21/22	Revisions made based on questions received from the EPA 09/23/22
Attachment G – COP Details_363C-27R_V3	3	01/11/23	Revisions made based on questions received from the EPA 01/11/23
Attachment G – COP Details_363C-27R_V4	4	05/14/2023	Revisions made based on questions received from the EPA 03/2023
Attachment D – Well Plugging Plan_363C-27R_V5	5	11/29/2023	Separating Construction and Plugging Plans into Separate Attachments

Introduction

CTV requires four injection wells for the Elk Hills 26R Storage Project. CTV intends to drill three new CO₂ injection wells and repurpose one existing well for CO₂ injection. Figure 1 identifies the wells proposed for the project.

All planned new wells will be constructed with components that are compatible with the injectate and formation fluids encountered such that corrosion rates and cumulative corrosion over the duration of the project are acceptable. The proposed well materials will be confirmed based on actual CO₂ composition such that material strength is sufficient to withstand all loads encountered throughout the life of the well with an acceptable safety factor incorporated into the design. Casing points will be verified by trained geologists using real-time drilling data such as LWD and mud logs to ensure protection of shallow formations. No USDW is present within the AoR. However, surface and intermediate casing strings will provide multiple barriers of protection for shallow formation. Cementing design, additives, and placement procedures will be sufficient to ensure isolation of the injection zone and protection of shallow formations using cementing materials that are compatible with injectate, formation fluids, and subsurface pressure and temperature conditions.




Figure 1: Map showing the location of injection wells and monitoring wells.

Figure 2 and *Appendix: 26R Injection and Monitoring Well Schematics* document provides casing diagram figures for all injection with construction specifications and anticipated completion details in graphical and/or tabular format.

Injection wells will have wellhead equipment sufficient to shut off injection at surface. The project does not anticipate risk factors that warrant downhole shut-off devices, such as high temperature, high pressure, presence of hydrogen sulfide, proximity to populated areas, or high likelihood of damage to the wellhead.

Injection Well Plugging

CTV will conduct injection well plugging and abandonment according to the procedures below. The proposed injection well plugging plan will ensure that the proposed materials and procedures for injection well plugging are appropriate to the well's construction and the site's geology and geochemistry.

Planned Tests or Measures to Determine Bottom-Hole Reservoir Pressure

Before beginning the plugging and abandonment process, the pressure used to squeeze the cement will be determined from the bottom-hole pressure gauge. During plugging operations, the heavy-weighted cement slurry, as well as properly weighted displacement fluids, will be over-balanced ensuring that no reservoir fluids will be able to enter the wellbore during cementing operations.

Planned External Mechanical Integrity Test(s)

CTV will conduct at least one external mechanical integrity test prior to plugging the monitoring well as required by 40 CFR 146.92(a). A temperature log or other approved external MIT will be run over the entire depth. The planned external MIT method will be a temperature log or other approved external MIT (Table 1) and the procedure will be EPA-approved and consistent with procedures outlined in the Testing and Monitoring Plan. If a temperature log is run for external MIT, the temperature data will be evaluated for anomalies in the temperature profile by comparing to baseline temperature data acquired prior to injection of CO₂ and during the injection phase. If another approved external MIT method is used, it will be compared to baseline pre-injection data and/or other data acquired throughout the injection phase which the EPA has deemed acceptable.

Table 1: External Mechanical Integrity Testing Methods

Test Description	Location
Temperature Decay Log	Along wellbore using wireline well log
Distributed Temperature Log (DTS)	Along wellbore using fiber optic sensing (DTS), continuous
Oxygen Activation Log (OA)	Along wellbore using wireline well log
Noise Log	Along wellbore using wireline well log

Information on Plugs

CTV will use the materials and methods noted in Table 2 to plug the injection well. The cement formulation and required certification documents will be submitted to the agency with the well plugging plan. The owner or operator will report the wet density and will retain duplicate samples of the cement used for each plug.

A standard portland cement blend will be designed with a minimum 1,000 psi compressive strength and a maximum liquid permeability of 0.1 mD. The properties of this cement blend will be at least equivalent to the properties of Class G portland cement, and the cement plug will provide an

effective, long-term barrier to prevent migration of CO₂ into and within the wellbore. This cement is widely used in CO₂-EOR wells and has been demonstrated to have properties that are not deleterious with CO₂.

The wells will have this cement placed as detailed in Table 2, and all portions of the wellbore that are not plugged with cement will be filled with sufficiently weighted abandonment mud. The cement will be set in plug segments per CTV's standard procedures.

Table 2: Plugging details

Plug Information	Plug #1	Plug #2	Plug #3	Plug #4
Diameter of boring in which plug will be placed (in.)	3.92	6.276	6.276	6.276
Depth to bottom of tubing or drill pipe (ft)	8300	2476	1054	39
Sacks of cement to be used (each plug)	154	24	24	5
Slurry volume to be pumped (bbl)	31.54	4.92	4.92	1.02
Slurry weight (lb./gal)	15.8	15.8	15.8	15.8
Calculated top of plug (ft)	6200	2351	929	14
Bottom of plug (ft)	8300	2476	1054	39
Type of cement or other material	Class G Portland	Class G Portland	Class G Portland	Class G Portland
Method of emplacement (e.g., balance method, retainer method, or two-plug method)	Balanced Plug, Retainer, or CT Plug			

Notifications, Permits, and Inspections

In compliance with 40 CFR 146.92(c), CTV will notify the regulatory agency at least 60 days before plugging the well and provide an updated Injection Well Plugging Plan.

Plugging Procedures

The following plugging procedures are planned assuming a coiled tubing unit (CTU) is utilized for cement plug placement after all completion equipment is removed. The placement method may vary depending on the type of service equipment used. For instance, a maintenance rig may place the cement plug of same specification at same depths using jointed pipe and achieve the same result.

1. Bottom hole pressure from down-hole pressure gauge is recorded and kill fluid density is calculated.

2. Kill fluid of appropriate density is bullheaded into the wellbore to prevent reservoir fluid inflow and acts as a buffer fluid to flush the wellbore. Wellbore Bullheading will be conducted at appropriate rates so as to ensure no fracturing of the surrounding formation occurs and the cement plugs are not compromised in any way. After at least one wellbore volume of fluid is pumped, the well is observed to ensure static conditions, which is an indication that (1) the weighted fluid is preventing fluid migration into the wellbore and (2) that there is no CO₂ in the wellbore. If CO₂ were present in the wellbore, it would migrate to surface due to density difference and expand in volume under decreasing hydrostatic pressure, resulting in non-static (flowing) conditions at surface.
3. Tubulars and downhole equipment are removed from the casing, and the well is cleaned out to TD during rig operations. Subsequent operations are carried out utilizing a coiled tubing unit (CTU).
4. The CTU runs in the hole to TD and begins placing cement in the casing. The coiled tubing is kept about 100' inside of the cement plug and is pulled up hole while cementing operations continue.
5. Once the full plug is placed, the coiled tubing is pulled above the plug and the well is circulated to ensure the depth of the top of the plug. The tubing is then pulled up hole while operations are paused to wait on cement.
6. Once the cement has set, the coiled tubing is run back in the hole to witness the depth and hardness of the plug before initiating the next cemented plug interval.
7. Abandonment mud is placed between cement plugs while pulling the coiled tubing up hole to the base of the next plug.
8. This process, beginning with step 4, is repeated for each cement plug until cement is placed to surface.
9. Once the fourth cement plug is placed at surface, casing will be cut 5' below ground level. A metal cap will be welded onto the top of the cut casing, stamped with the well name and API. Surface location will then be backfilled and restored to pre-operation conditions.

CRC follows the following standards for plugging operations:

- Bottomhole plug - All perforations shall be plugged with cement, and the plug shall extend at least 100 feet above the top of a landed liner, the uppermost perforations, the casing cementing point, the water shut-off holes, or the oil or gas zone, whichever is highest.
- Base of USDW plug (Underground Source of Drinking Water is defined as a non-exempt aquifer that has <10,000 mg/L TDS):
 - If there is cement behind the casing across the base of USDW, a 100-foot cement plug shall be placed inside the casing across the interface.
 - If the top of the cement behind the casing is below the base of the USDW, squeeze-cementing shall be required through perforations to protect the freshwater deposits.

In addition, a 100-foot cement plug shall be placed inside the casing across the fresh-saltwater interface.

- In 26R, this interval would be located at the top of the San Joaquin formation.
- Surface Plug - The casing and all annuli shall be plugged at the surface with at least a 25-foot cement plug.




Figure 2: Injection Well 363C-27R, Abandonment Schematic